TcpTUNNEL Scan

1

Installation Guide

www.aplitop.com

aplitop

info@aplitop.com

1. SYSTEM REQUIREMENTS 3
2. PROGRAM INSTALLATION 4
3. LICENSE ACTIVATION 6

1. System requirements

The minimum system requirements for running **TcpTunnel Scan** are:

Processor	**x86**
Operating system	**Windows 10 (64 bits)**
GPU	**OpenGL 3.0+ support**
RAM memory	**8 GB**
Conectivity	**Bluetooth**
Screen resolution (*****)	**WXGA (1280x800) with text scale 125%**

2. Program installation

To install **TcpTunnel Scan** on the device, the next steps must be followed:

- Extract the zip file containing the executable program. The name of this file has the format **<date>_tcptunnelscan_<version>.zip**.

- Run the installation file.

- Select the language. The available options are english and spanish. Then, click ***OK*** button.

- Select the installation folder and click ***Next*** button.



- Select the Windows Start Menu folder and click ***Next*** button.



- Click ***Install*** button.





- Click ***Finish*** button to restart the computer.



- A shortcut to the program will created in **Aplitop** folder, within Windows Start Menu, and on the desktop.

3. License activation

To activate the license for **TcpTunnel Scan**, it will be necessary Internet connection during the first execution of the program and the configuration of communications with the selected total station.

There are 3 types of license, **DEMO** (30 days), **FINAL** (permanent), **365** (annual). For these last two licenses, it will be necessary to enter an activation code of **20** and **16** characters, respectively.

The next steps must be followed:

- Run **TcpTunnel Scan**.

- Enter the Email, the Country and enable the check box ***Accept the Data Privacy Policy***.



- For **FINAL** o **365** license, enable the option ***Enter an activation code*** and write, on ***Code*** edit box, the activation code supplied.

- Click OK button to start the activation process.