



|  | Windows |          | Android |     | iOS  |
|--|---------|----------|---------|-----|------|
|  | Basic   | Advanced | Basic   | Pro | Lite |
| <b>BASE MAPS</b>                                       |         |          |         |     |      |
| Web map services                                       | ■       | ■        | ■       | ■   |      |
| DXF Files  | ■       | ■        | ■       | ■   |      |
| DWG Files  |         |          | ■       | ■   |      |
| Shape Files  | ■       | ■        | ■       | ■   |      |
| Google Maps  |         |          |         |     |      |
| Apple Maps   |         |          |         |     | ■    |
| Esri Maps  |         |          | ■       | ■   |      |
| Orthophotos  | ■       | ■        |         |     |      |
| <b>GNSS RECEIVER CONTROL <sup>(1)</sup></b>            |         |          |         |     |      |
| Connection to integrated GPS                           | ■       | ■        | ■       | ■   | ■    |
| Connection to external receiver through Bluetooth      | ■       | ■        | ■       | ■   |      |
| Connection to external receiver through serial cable   | ■       | ■        |         |     |      |
| Real-time coordinate display in several formats        | ■       | ■        | ■       | ■   | ■    |
| Display of satellite constellation and status          | ■       | ■        | ■       | ■   |      |
| Receiver configuration in RTK mode by UHF, GPRS or GSM | ■       | ■        | ■       | ■   |      |
| Receiver configuration for postprocess                 | ■       | ■        | ■       | ■   |      |
| Work styles configuration                              | ■       | ■        |         |     |      |
| <b>SURVEY</b>  |         |          |         |     |      |
| Point survey   | ■       | ■        | ■       | ■   | ■    |
| Continuous survey                                      | ■       | ■        | ■       | ■   | ■    |
| Point codes data base                                  | ■       | ■        | ■       | ■   | ■    |
| Link pictures to points                                |         |          | ■       | ■   | ■    |
| Link voice notes to points                             |         |          | ■       | ■   |      |
| Horizontal and vertical alignment survey               |         | ■        |         |     |      |
| Profiles survey  |         | ■        |         |     |      |
| Google Drive synchronization                           |         |          | ■       | ■   |      |
| <b>STAKE OUT</b>                                       |         |          |         |     |      |
| Map mode   | ■       | ■        | ■       | ■   |      |
| Compass mode   | ■       | ■        | ■       | ■   |      |
| Dartboard mode   | ■       | ■        | ■       | ■   |      |
| Augmented reality mode                                 |         |          |         | ■   |      |
| Points   | ■       | ■        | ■       | ■   |      |
| Lines  | ■       | ■        | ■       | ■   |      |
| Lines intersection                                     | ■       | ■        |         | ■   |      |
| Polylines  |         | ■        |         | ■   |      |
| Station and offset                                     |         | ■        |         | ■   |      |
| Station and code                                       |         | ■        |         | ■   |      |
| Slope control  |         | ■        |         | ■   |      |
| Simple template  |         | ■        |         | ■   |      |
| Voice instructions                                     | ■       | ■        | ■       | ■   |      |
| <b>POINTS MANAGEMENT</b>                               |         |          |         |     |      |
| Importing in several formats                           | ■       | ■        | ■       | ■   |      |
| Point editing  | ■       | ■        | ■       | ■   | ■    |
| Drawing of points                                      | ■       | ■        | ■       | ■   | ■    |
| Displacement of points                                 | ■       | ■        |         |     |      |
| Rotation of points                                     | ■       | ■        |         |     |      |
| Export to KML  |         |          | ■       | ■   | ■    |
| Export to DXF  |         |          | ■       | ■   | ■    |
| Export to text   | ■       | ■        | ■       | ■   | ■    |
| Raw data management                                    | ■       | ■        | ■       | ■   |      |
| <b>LOCAL COORDINATE SYSTEMS</b>                        |         |          |         |     |      |
| Creation of local systems by parameters                | ■       | ■        |         |     |      |
| Creation of local systems by point pairs               | ■       | ■        | ■       | ■   |      |
| Importation from other projects                        | ■       | ■        | ■       | ■   |      |
| Quick placement in local system                        | ■       | ■        |         |     |      |
| <b>PROJECTS AND LINEAR WORKS</b>                       |         |          |         |     |      |
| Horizontal alignments                                  |         | ■        |         | ■   |      |
| Vertical alignments                                    |         | ■        |         | ■   |      |
| Profiles   | ■       |          |         | ■   |      |
| Cross sections   |         | ■        |         | ■   |      |
| Superelevations  |         | ■        |         | ■   |      |
| Surfaces   | ■       | ■        |         | ■   |      |
| LandXML import   |         |          |         | ■   |      |
| Creation of DTM from points and breaklines             |         |          |         | ■   |      |
| Generation of contour lines                            |         |          |         | ■   |      |
| <b>TOOLS</b>   |         |          |         |     |      |
| Calculation of points over alignment                   |         | ■        |         |     |      |
| Point analysis over surface                            |         | ■        |         | ■   |      |
| Point analysis over alignment                          | ■       | ■        |         | ■   |      |
| Distance and area calculation                          | ■       | ■        | ■       | ■   | ■    |
| Geodesic calculator                                    | ■       | ■        |         |     |      |
| Line and circle intersections                          | ■       | ■        |         | ■   |      |
| Conversion from polar to rectangular coordinates       | ■       | ■        |         |     |      |
| <b>CONFIGURATION</b>                                   |         |          |         |     |      |
| Survey configuration                                   | ■       | ■        | ■       | ■   | ■    |
| Stake out configuration                                | ■       | ■        | ■       | ■   |      |
| Coordinate systems management                          | ■       | ■        | ■       | ■   |      |
| Sounds and voice                                       | ■       | ■        | ■       | ■   |      |
| Laser distancemeter support                            | ■       | ■        |         |     |      |
| Eco-sound support                                      | ■       | ■        |         |     |      |

NOTES:

(1) Depending on receiver brand and model. Consult specific technical notes.